



Linking up Remote Controls to the HPA

It is advisable for the dealer to introduce new remote controls into the alarm system.

NB. All remote controls must be pre-coded to the number issued on the orange card supplied with the alarm. The override pin-code from the card is also required to access the programming routine.

Please ensure that you have these details before commencing.

1. Arm and disarm the control unit with the remote control for a total of 16 times in all. The MO2 siren will now make 2 BEEPS followed by 2 BOOPS. The SC1 siren will make 2 BEEPS followed by 4 beeps.
2. Turn the ignition key ON within 10 secs (vehicles dashboard is turned on);
3. Press button A on the new remote control: the LED turns on;
4. Press button A on the same remote control again: the LED turns off and the siren makes a BEEP to confirm that it has been successfully linked up
5. Press button A on the second new remote control: the LED turns on;
6. Press button A on the same remote control again: the LED turns off and the siren makes a BEEP to confirm it has been successfully linked up;
7. Repeat steps 5 and 6 for all the new remote controls;
8. Turn the ignition key OFF (vehicle's dashboard is turned off: the MO2 siren will make 2 BEEPS and 2 BOOPS to signal the remote controls have been stored in the control unit's memory; the SC1 siren will make 4 BIPS.